


### IGT Manual change over valve system presentation





#### What does the system do?

To keep your gas supply continuously. Just easily switch the knob to either of the gas filled cylinders, left or right side.

#### Optional Manometer:


equipped with or without manometer the alternative of the panel diameter is 35mm or 40 mm .

#### Optional Bracket:

with or without a galvanized metalbracket, with which can be mounted on your wall.

Application medium LPG , Butane , Propane or their mixture


Work pressure 20 bar






#### What does the system comprise of

Change over valve +A400 regulator + Hose assembly= Manual change over system








A400 LPG gas regulator with various inlet and outlet connection options	
Inlet connection options (B)	G1,G2,G4,G5,G10
Outlet connection options (C)	G2 ( W21.8x1.814), W21x1.814 ID 8mm hose , ID10 mm hose, 3/8" LH,
Guaranteed flow rate	4 kg/h
Supply pressure	0.3~16 bar
Set pressure	30 mbar, 37 mbar , 50 mbar


With different inserts on mold of the body, this part is changeable.

there are various outlet connections for selection









Just move the mouse left button on the picture.

A play button will display on the bottom, Click it then run the animation.